



General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the hot valve:

1. Loosen grub screw (D1) on the underside of handle (D2) using a 2mm A/F allen key.
2. Pull the handle (D2) away from the tap body (B1).
3. Hold the body of the tap (B1) firmly. Using an adjustable or 17mm ring spanner unscrew the valve (D3).
4. Clean the Inside of chamber (B1) with a soft wet cloth.
5. Reassemble the tap in the reverse order.

To replace the spout o-rings:

1. Loosen grub screw (A8) on the rear of the body (B1) using a 2.5mm A/F allen key.
2. Whilst holding body (B1) pull the spout (A4) vertically, using a twisting action if required.
3. Remove the old o-ring (A6) using a small screwdriver or similar.
4. If worn, remove the white PTFE rings (A5 & A7).
5. Ensure the inside of the body (B1) and the spout base (A4) is clean of dirt and grit.
6. If required locate the new white PTFE spacers rings (A5 & A7).
7. Carefully locate the new O-ring (A6) onto the spout base (A4).
8. Grease the O-ring (A6) thoroughly with silicone or alternative similar grease.

Note: the PTFE rings (A5 & A7) are designed to be a one way snap fit, when removing the spout some force may be required.

To improve the water flow rate:

1. Unscrew the aerator housing (A1)
2. Remove aerator (A2) installed in the tap and replace with the high flow aerator (A2B) supplied separately with the tap.
3. Reassemble the aerator in the reverse order.