abode

Atlas Aquifier

Product Finish: Chrome	Product code: AT2003 EAN13 barcode: 5060048381	245
	Product features:	
(I)	Metal construction throughout	
	 Push the cold lever backwards for crystal clear filtered water, easy t change, high quality carbon filter 	
	Supplied compete with installation kit and filter cartridge	
	Quarter turn handle action for precise flow control	
	Antisplash spout supplied as standard	
	Additional information / Parts included:	
	Note: sufficient space behind the tap should be available to allow the colo handle to rotate backwards, includes 17mm box spanner, SCO 06041	
Note: the image shown may not reflect the product finish, chrome finish is typically depicted.		
Product dimensions:	• Overall Height / prejection	
	 Overall Height / projection Exit reach: 216 mm Exit height: 266 mm Centre distance(s): 	. 391 mm
	 Base diameter(s): 60 mm Recommended hole diameter: Ø 35 mm Max. surface depth: 40 mm 	
	 Spout diameter: 24 mm Spout aerator size: 22f 	
	Packaged properties:	
	Box length: 575mm	Box depth: 80mm
_ 60 _	Box width: 350mm	Units per outer: 5
ATLAS AQUIFIER Interview and the second of t	Tap only weight: 2.32kg	Boxed weight: 4.14kg
Product flow characteristics:	• Min / Max water pressure: 0.3	0 / 5.50 bar
Flow performance for model: Atlas aquifier	 Recommended / Max water temperature: 46°C / 70°C Part G - Mixed flow rate at 3 bar (litres / min): 16.00 	
and a second sec	 Control valve type: Ceramic disc QT Product flow characteristics: (C&F / H) dual flow Non return valve(s): No, none required Aerator type: Flow straightener (fitted) + optional hi-flow Accepts revolve / spray areator: Yes Spout connection method: Grub screw 	
0 0 0 0 0 0 0 0 0 0 0 0 0 0		
I Bash, set is in productive programmer. Black, set is in productive programmer. Proving productive programmer and provide productive set is set in an end productive set of the set of the productive set of the	 Tail pipe inlet / outlet size: M12 / 15mm Ø Inlet pipe type / length: copper rigid tube / 245 mm 	
are instructions summary: Clean the mixers and showers regularly as required, using soap, do not use any other clear Regular cleaning will prevent the build-up of lime scale and dirt After cleaning rinse thoroughly with clean water to remove any cleaner residue Residues of sink & worktop cleaners can also cause damage, so rinse with clean water afte	Warranty Summary (Full details available on mers. Materials and workmanship defects warranted for Valves and working parts warranted for Surface warranty defects warranted for	equest): ranted for 5 years 5 years 1 year