



General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the cold valve:

1. Remove dust cap (D1) from the underside of handle (D3).
2. Loosen grub screw (D2) on the underside of handle (D1) using a 2.5mm A/F Allen key.
3. Pull handle (D3) horizontally away from the body (B1).
4. Unscrew decorative cover (D7) by hand and away from valve (D8).
5. Using an adjustable spanner or socket unscrew valve (D8) anticlockwise.
6. Replace the faulty valve (D8) with the new one and assemble in reverse order.

To replace the spout O-rings:

1. Loosen grub screw (A9) on the rear of body (B1) using a 2.5mm A/F Allen key.
2. Pull the spout (A4) vertically away from the body (B1).
3. Remove the old O-rings (A6 & A7) using a small screwdriver or similar.
4. If worn, remove the white PTFE spacers (A5 & A8).
5. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
6. If required locate the new white PTFE spacers (A5 & A8).
7. Carefully locate the new O-rings (A6 & A7) onto the spout base (A4).
8. Grease the O-rings thoroughly with silicone or alternative similar grease.
9. Reassemble the tap in the reverse order.

To clean the aerator:

1. Unscrew the aerator housing (A1) by hand.
2. Clean the aerator (A2).
3. Screw aerator case (A1) back onto spout ensuring seal (A3) is in place as shown.

To replace the aerator with a flow limited aerator:

1. Unscrew aerator case (A1) by hand.
2. Replace standard flow aerator (A2) with 5 lpm flow aerator (A10).
3. Screw aerator case (A1) back onto spout ensuring seal (A3) is in place as shown.

Changing Lever design:

1. Unscrew ceramic lever (D4) and decorative top (D6) by hand and pull vertically away from handle base stem (D3).
2. Place solid metal handle (D5) onto stem of handle base (D3).
3. Screw decorative top (D6) onto top of handle base stem (D3) to tighten handle in place.