



R27 Important to the fabricator / installer. The cut out size indicated its flush with the bow degw that animum radius where appropriate. You should confine with your client if the worksourface cutout is to be cut (list), hostler or othside this suggested of you create the cutout snaller or larger than the indicated size then some accessories may not fit correctly. All defails are provided in good faith and within the roterances of the worksourface committing to cutting the worksourface. Abode can not accept liability for professions or cuts in curred by failure 1 years. Aw5095 v1 (c) abode 2009

534

UNDERMOUNT CUT OUT