


Astbury Monobloc with Spray

abode



Astbury Monobloc with Spray

abode

General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the hot valve:

1. Unscrew grub screw (C2) using a 2mm Allen key.
2. Pull handle (C1) away from valve (C4)
3. Unscrew decorative valve cover (C3) from valve (C4) by hand.
4. Using a 17mm ring spanner and whilst holding the tap body (B1) firmly, unscrew and remove hot valve (C4).
5. Clean the inside of the valve chamber of the tap body (B1) with a soft damp cloth.
6. Locate the new valve (C4) and reassemble the tap in reverse order.

To replace the spout o-rings:

1. Fully unscrew spout locking collar (A3) by hand.
2. Gently ease away spout (A2) from tap body.
3. With a soft damp cloth clean the inside of spout chamber (B1)
4. Remove worn o-rings (A5) and PTFE ring (A4) using a precision screwdriver.
5. Reassemble the tap with the new PTFE ring (A4) and o-rings (A5) in reverse order.

To replace the diverter:

1. Fully unscrew spout locking collar (A3) by hand.
2. Gently ease away spout (A2) from tap body.
3. With the provided diverter removal tool unscrew the diverter valve (A6)
4. With a soft damp cloth clean the inside of spout chamber (B1)
5. Replace the new diverter (A6) and reassemble the tap in reverse order.

To replace the handspray and seal:

1. Lift handspray (H1) from base (K1)
2. Unscrew handspray (H1) from hose connection (J1)
3. Screw the new handspray onto connection (J1) ensuring rubber seal (H3) is in place.

To convert the tap to have a independent cold spray:

In case of low pressure supply, parts required from abode M15 male stop end, 1/2" Male x M15 female adapter.

1. Unscrew spout locking collar (A3) and remove the spout.
2. Unscrew diverter (A6) from the tap body (B1) it does not matter if the diverter (A6) is damaged in the process.
3. Disconnect the spray hose (J3) from outlet pipe (G1).
4. Screw the M15 male stop end (not shown) into the outlet pipe (G1). Ensure to use the 15mm seal.
5. Screw the spray hose (J3) into the 1/2" Male x M15 female adapter (not shown) using the 15mm seal.
6. Connect the 1/2" Male x M15 female adapter to a tee from your cold water supply. Please note that the maximum cold water pressure should be no more than 2 bar. If the pressure is higher then a pressure reducing valve must be installed.